21
20
19
18
17
DRIVE
DRIVE
DRIVE
DRIVE
DRIVE
230'SETBACK
245'SETBACK
240'SETBACK
35'SETBACK
83'SETBACK
BUFFER
SHORELINE
ORMAN