GRAVEL DR

AROUND THE SITE TO CONTAIN ALL RUNOFF DUE TO CONSTRUCTION.

2. INSTALL ALL EROSION CONTROL DEVICES AROUND THE PERIMETER OF SITE ONLY. (DITCH 1, DITCH2 AND SILT BASIN 1)
3. CALL ENGINEER FOR APPROVAL TO CONTINUE OR TO SCHEDULE INSPECTION.
4. CLEAR AND GRUB REMAINDER OF SITE.
5. INSTALL REMAINDER OF EROSION CONTROL DEVICES AS REQUIRED.
6. STRIP AND STOCKPILE TOPSOIL AS REQUIRED.
7. COMPLETE GRADING AND APPLY PERMANENT SEEDING PER SCHEDULE.
8. MAINTAIN ALL EROSION CONTROL DEVICES UNTIL PERMANENT VEGETATION HAS BEEN ESTABLISHED.
9. APPLY STRAW AND ASPHALT TACK TO ALL CUT AND FILL SLOPES 3:1 OR GREATER.
10. TEMPORARY SEEDING TO BE APPLIED ON ALL CUT & FILL SLOPES AS SOON AS POSSIBLE DURING CONSTRUCTION (14 DAYS MAXIMUM).

